


Obey™ 3

Quick Startup Guide



Revision 01
CHAUVET®, 2010, All Rights Reserved
Information and specifications in this User Manual are subject to change without notice.
CHAUVET® assumes no responsibility or liability for any errors or inaccuracies that may appear in this manual.



3000 N 29th Ct, Hollywood, FL 33020 U.S.A.
(800) 762-1084 – (954) 929-1115
FAX (954) 929-5560
www.chauvetlighting.com

- Setup**
1. Using the provided power supply, plug the controller into electricity and turn it on.
 2. Plug the light(s) into electricity and turn it/them on.
 3. Connect a DMX cable from the controller to the light(s).

- Operation:
(Preset Colors)**
1. Press the **<BLACKOUT>** button to disable it (LED indicator OFF).
 2. Slide the **<FADE TIME>** fader (middle) and the **<DIMMER FADER>** (right) all the way up.
 3. Press the **<PRESET>** button to illuminate the LED indicator above the button.
 4. Press one of the 9 preset color buttons to select a color.
 5. Slide the **<FADE TIME>** fader (middle) to adjust the amount of time to change from one color to another color.
 6. To add a strobe, press the **<STROBE>** button to illuminate the LED next to it, then slide the **<SPEED TIME>** fader (middle) to the required strobe rate. Press the **<STROBE>** button again to deactivate the strobe button from the middle fader.



*To stop the fixture from strobing, make sure the strobe function is activated and slide the middle fader all the way down, then press the **<STROBE>** button to deactivate the function from the middle fader.*

Miscellaneous Notes In **<CHASES>** & **<MACRO>** & **<PRESET>** operating modes, the **<DIMMER>** fader (right) must be set at the top to see full output from the lights. Set this fader down to adjust the master intensity of all connected lights.

The **<CHASES>** & **<MACRO>** buttons on the lower, left work along with all three faders.

Pressing the **<BLACKOUT>** button will turn off the output of the lights, and will also work along with the **<FADE TIME>** fader (middle).

The Obey™ 3 is designed to be used with 3 channel, red/green/blue fixtures.

SEE USER MANUAL

This is a Quick Start Guide. It is not intended to be used as a full User Manual. Please see the User Manual for a full set of safety warning, disclaimers, instructions and specifications.

*It's
Green Thinking*

Contact Us

General Information

CHAUVET®
3000 North 29th Court
Hollywood, FL 33020
Voice: (954) 929-1115
Fax: (954) 929-5560

World Wide Web

www.chauvetlighting.com