

LX5™

## Snapshot

OK on Dimmer	⊘
Outdoor OK	⊘
Sound Activated	✓
DMX512	⊘
Master/Slave	⊘
115V/230V Switch	✓
Replaceable Fuse	✓
User Serviceable	⊘
Duty Cycle	⊘

USER MANUAL



Chauvet, 5200 NW 108th Avenue, Sunrise, FL 33351 U.S.A.  
(800) 762-1084 – (954) 929-1115  
FAX (954) 929-5560  
[www.chauvetlighting.com](http://www.chauvetlighting.com)

# TABLE OF CONTENTS

<b>1. BEFORE YOU BEGIN.....</b>	<b>3</b>
WHAT IS INCLUDED.....	3
UNPACKING INSTRUCTIONS.....	3
AC POWER.....	3
SAFETY INSTRUCTIONS.....	3
<b>2. INTRODUCTION .....</b>	<b>4</b>
FEATURES.....	4
PRODUCT OVERVIEW .....	4
<b>3. SETUP .....</b>	<b>5</b>
FUSE REPLACEMENT .....	5
MOUNTING .....	5
Orientation .....	5
Rigging.....	5
<b>4. OPERATING INSTRUCTIONS.....</b>	<b>5</b>
GENERAL TROUBLESHOOTING.....	6
GENERAL MAINTENANCE .....	7
RETURNS PROCEDURE .....	7
CLAIMS .....	7
TECHNICAL SPECIFICATIONS .....	8
CONTACT US .....	8

# 1. BEFORE YOU BEGIN

## What is Included

- 1 x LX5™
- Power Cord
- Warranty Card
- User Manual

## Unpacking Instructions

Immediately upon receiving a product, carefully unpack the carton and check the contents to ensure that all parts are present, and have been received in good condition. Notify the shipper immediately and retain packing material for inspection if any parts appear damaged or the carton shows signs of mishandling. Save the carton and all packing materials.

## AC Power

To determine the power requirements for a particular product, see the label affixed to the back plate of the product or refer to the product's specifications chart. A product's listed current rating is its average current draw under normal conditions. All products must be powered directly off a switched circuit and cannot be run off a rheostat (variable resistor) or dimmer circuit, even if the rheostat or dimmer channel is used solely for a 0 to 100% switch. Before applying power to a product, check that the source voltage matches the product's requirement. Check the product or device carefully to make sure that if a voltage selection switch exists that it is set to the correct line voltage you will use.

Figure 1 - AC Voltage Switch



### Warning!

**Verify that the voltage select switch on your unit matches the line voltage applied. Damage to your product may result if the line voltage applied does not match the voltage indicated on the voltage selector switch. All products must be connected to circuits with a suitable Earth Ground.**

Not all products have a voltage select switch. Please be sure to connect to the proper voltage.

## Safety Instructions



Please read these instructions carefully, they include important information about the installation, usage, and maintenance of this product.

- Please keep this User Manual for future consultation. If you sell the unit to another user, be sure that they also receive this instruction booklet.
- Always make sure that you are connecting to the proper voltage, and that the line voltage you are connecting to is not higher than that stated on the decal or rear panel of the product.
- This product is intended for indoor use only! To prevent risk of fire or shock, do not expose product to rain or moisture. Make sure there are no flammable materials close to the unit while operating.
- The unit must be installed in a location with adequate ventilation, at least 20in (50cm) from adjacent surfaces. Be sure that no ventilation slots are blocked.
- Always disconnect from power source before servicing or replacing fuse and be sure to replace with same fuse size and type.
- Secure product to fastening device using a safety chain. Never carry the product solely by its head. Use its carrying handles.
- Maximum ambient temperature (Ta) is 104°F (40°C). Do not operate product at temperatures higher than this.
- In the event of a serious operating problem, stop using the unit immediately. Never try to repair the unit by yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center. Always use the same type spare parts.
- Never connect the device to a dimmer pack.
- Make sure the power cord is never crimped or damaged.
- Never disconnect the power cord by pulling or tugging on the cord.
- Avoid direct eye exposure to the light source while it is on.
- Do not daisy chain power to more than 50 units.

### Caution!


**There are no-user serviceable parts. Do not open the housing or attempt any repairs yourself. In the unlikely event your unit may require service, please contact CHAUVET® at: 954-929-1115.**

# 2. INTRODUCTION

## Features

- LED moonflower effect
- Selectable functions: sound, rotating, static
- Additional power output for daisy chaining units (max 50 units)
- Sound sensitivity knob
- Ultra-bright LEDs
- Low power consumption

## Product Overview



# 3. SETUP




Disconnect the power cord before replacing a fuse and always replace with the same type fuse.



## Fuse Replacement

With a flat-head screwdriver wedge the fuse holder out of its housing. Remove the damaged fuse from its holder and replace with exact same type fuse. Insert the fuse holder back in its place and reconnect power.

The fuse is located inside this compartment. Remove using a flat head screwdriver.



## Mounting

### Orientation


This product may be mounted in any position provided there is adequate room for ventilation.

### Rigging

It is important never to obstruct the fan or vents pathway. Mount the product using, a suitable "C" or "O" type clamp. Adjust the angle of the product by loosening both knobs and tilting the product. After finding the desired position, retighten both knobs.

- When selecting installation location, take into consideration lamp replacement access and routine maintenance.
- Safety cables must always be used.
- Never mount in places where the product will be exposed to rain, high humidity, extreme temperature changes or restricted ventilation.

*Hanging Clamp*



Note!  
Clamp is sold separately.

# 4. OPERATING INSTRUCTIONS

The LX5 can operate in Sound-Active or Auto mode, which is determined by the position of the switch located on the rear of the unit. The mode of the unit refers to the reaction of the LEDs only as there are no moving parts in the unit. To switch between the two modes, place the switch in either the "I" or "O" position.

In the "I" position, the product operates in Sound-Active mode, the sensitivity of which can be adjusted by the knob also located on the rear of the unit. To increase the sensitivity of the unit rotate the knob clockwise.

In Auto Mode, the light will progress through a pre-programmed routine, whether sound is present or not.

## General Troubleshooting

Symptom	Solution(s)	Applies to			
		Lights	Foggers & Snow	Controllers	Dimmers & Chaser
Auto shut off	Check fan thermal switch reset	✓			
Beam is very dim or not bright	Clean optical system or replace lamp Check 220/110v switch for proper setting	✓			
Breaker/Fuse keeps blowing	Check total load placed on device				✓
Chase is too slow	Check users manual for speed adjustment	✓		✓	✓
Device has no power	Check for power on Mains. Check device's fuse. (internal and/or external)	✓		✓	✓
Product is on but there is no movement to the audio	Make sure you have the correct audio mode on the control switches. If audio provided via ¼" jack, make sure a live audio signal exists Adjust sound sensitivity knob	✓		✓	✓
Lamps cuts off sporadically	Possible bad lamp or product is overheating. Lamp may be at end of its life.	✓			
Light will not come on after power failure	Some discharge lamps require a cooling off period before the electronics in the product can kick start it again, wait 5 to 10 minutes before powering up	✓			
Moves slow	Check 220/110v switch for proper setting	✓			
No flash	Re-install bulb, may have shifted in shipping	✓			
No light output	Check slip ring & brushes for contact Install bulb Call service technician	✓			
Relay will not work	Check reset switch Check cable connections				✓
Remote does not work	Make sure connector is firmly connected to device	✓	✓		
Stand alone mode	All Chauvet lighting products featuring stand-alone functions do not require additional settings, simply power the product and it will automatically enter into this mode	✓			

**If you still have a problem after trying these solutions, please contact CHAUVET® Technical Support.**

## General Maintenance

To maintain optimum performance and minimize wear products should be cleaned frequently. Usage and environment are contributing factors in determining frequency. As a general rule, products should be cleaned at least twice a month. Dust build up reduces light output performance and can cause overheating. This can lead to reduced lamp life and increased mechanical wear. Be sure to power off product before conducting maintenance.

Unplug product from power. Use a vacuum or air compressor and a soft brush to remove dust collected on external vents and internal components. Clean all glass when the product is cold with a mild solution of glass cleaner or Isopropyl Alcohol and a soft lint free cotton cloth or lens tissue. Apply solution to the cloth or tissue and drag dirt and grime to the outside of the lens. Gently polish optical surfaces until they are free of haze and lint.

The cleaning of internal and external optical lenses and/or mirrors must be carried out periodically to optimize light output. Cleaning frequency depends on the environment in which the product operates: damp, smoky or particularly dirty surrounding can cause greater accumulation of dirt on the unit's optics. Clean with soft cloth using normal glass cleaning fluid. - Always dry the parts carefully. - Clean the external optics at least every 20 days. Clean the internal optics at least every 30/60 days.

## Returns Procedure

Returned merchandise must be sent prepaid and in the original packing, call tags will not be issued. Package must be clearly labeled with a Return Merchandise Authorization Number (RA #). Products returned without an RA # will be refused. Call CHAUVET and request RA # prior to shipping the product. Be prepared to provide the model number, serial number and a brief description of the cause for the return. Be sure to properly pack product, any shipping damage resulting from inadequate packaging is the customer's responsibility. CHAUVET reserves the right to use its own discretion to repair or replace product(s). As a suggestion, proper UPS packing or double-boxing is always a safe method to use.

**Note:** If you are given an RA #, please include the following information on a piece of paper inside the box:

- 1) Your name
- 2) Your address
- 3) Your phone number
- 4) The RA #
- 5) A brief description of the symptoms

## Claims

Damage incurred in shipping is the responsibility of the shipper; therefore the damage must be reported to the carrier upon receipt of merchandise. It is the customer's responsibility to notify and submit claims with the shipper in the event that a product is damaged due to shipping. Any other claim for items such as missing component/part, damage not related to shipping, and concealed damage, must be made within seven (7) days of receiving merchandise.

## Technical Specifications

### WEIGHT & DIMENSIONS

Length..... 8.8 in (224 mm)  
Width ..... 5.3 in (135 mm)  
Height ..... 8.5 in (216 mm)  
Weight ..... 3.5 lbs (1.6 kg)

### POWER

Switch-selectable power settings ..... 120V 60Hz AC or 230V 50Hz  
Fuse..... 1A 250V  
Power Consumption ..... 7.8W (0.08A) max at 120V  
Inrush Power ..... 11.4W (0.15A) at 120V  
Power Factor ..... 0.65 at 120V  
Power Output..... 50 units max at 110V, 100 units max at 230V

### LIGHT SOURCE

LED..... 57 (17 Red, 24 Green, 16 Blue) 100,000 hrs

### PHOTO OPTIC

Beam Angle ..... 42.7°

### THERMAL

Maximum ambient temperature..... 104°F (40°C)

### ORDERING INFORMATION

LX5 ..... LX5

### WARRANTY INFORMATION

Warranty ..... 1-year limited warranty

## Contact Us

### World Wide

#### *General Information*

Chauvet Lighting  
5200 NW 108th Avenue  
Sunrise, FL 33351  
voice: 954.929.1115  
fax: 954.929.5560  
toll free: 800.762.1084

#### *Technical Support*

Chauvet Lighting  
5200 NW 108th Avenue  
Sunrise, FL 33351  
voice: 954.929.1115 (**Press 4**)  
fax: 954.929.5560 (**Attention: Service**)

#### **World Wide Web**

[www.chauvetlighting.com](http://www.chauvetlighting.com)